

ILLUSONIC

Updating the Illusonic Audio Processor

Separate packages are available for Windows and OS X.
These instructions are for Windows.

1. USB connection

- a) Connect the IAP via USB to your computer. Use the USB CTRL port on the IAP.
- b) Turn on the power switch on the back.
- c) If the Found New Hardware Wizard pops up, click on Install the software automatically.

2. Firmware update

- a) Double-click the file: `Firmware Update/firmware_update.cmd`
- b) A command prompt will pop up.
- c) Answer `y` at the prompt to update the firmware.
- d) Let it run until `SUCCESS` appears.
- e) Press any key to close the prompt.

3. Done

You may now disconnect the USB cable.

Notes:

All settings from the Illusonic Audio Processor are preserved.

Settings are saved in a text file located at:

`%APPDATA%\Illusonic\iap_settings.txt`

Up to 10 previous versions of the file are kept with suffix `.0` to `.9`.

Regarding questions and support, get back to us: support@illusonic.com